

AN13591

FlexSPI CoreMark Performance on LPC553x/LPC55S3x

Rev. 3 — 20 September 2023

Application note

Document Information

Information	Content
Keywords	AN13591, FlexSPI, CoreMark, Octal NOR flash, LPC553x, LPC55S3x, CoreMark performance
Abstract	This document emphasizes on how to port CoreMark project and run on external FlexSPI interface, including octal NOR flash and HyperRAM. It provides test results of FlexSPI CoreMark performance data.



1 Introduction

CoreMark of EEMBC is a benchmark that measures the performance of microcontrollers (MCUs) and Central Processing Units (CPUs) used in embedded systems. It implements the following algorithms:

- List processing (find and sort)
- Matrix manipulation (common matrix operations)
- State machine (determines whether an input stream contains valid numbers)
- Cyclic redundancy check (CRC)

FlexSPI is a new peripheral for the LPC553x/LPC55S3x series. It expands code of application and data size. It brings opportunities of many new application designs.

This document emphasizes on how to port a CoreMark project and run on an external FlexSPI interface, including octal NOR flash and HyperRAM. It provides test results of FlexSPI CoreMark performance data.

Note:

Two prerequisite application notes are listed here:

1. *LPC553x/LPC55S3x CoreMark on Cortex-M33 Porting Guide* (document [AN13579](#)).
This document guides how to port a CoreMark project on LPC553x/LPC55S3x and gives a comprehensive view of the key point when evaluating a CoreMark project.
2. *Programming and Booting Images from External NOR flash on LPC553x/LPC55S3x* (document [AN13543](#)).
This document introduces how to create an external NOR flash image and how to boot the image from external NOR flash.

This document heavily reuses the two application notes. If you are not familiar with basic knowledge related to FlexSPI or CoreMark, read them first.

2 Porting CoreMark project to FlexSPI external memory

The difference between a normal internal flash image and a FlexSPI image is the code space address. Because the FlexSPI AHB address space started is `0x0800_0000`. Boot ROM defines that any FlexSPI image code execution address starts at `0x0800_1000`. We must change the linker file of the CoreMark project.

2.1 Getting CoreMark demo source code

This document reuses a CoreMark demo source code package available with *LPC553x/LPC55S3x CoreMark on Cortex-M33 Porting Guide* (Document [AN13579](#)). It provides a ready-to-use CoreMark project package for all three IDEs. For an original source code, the CoreMark data are running on internal flash and internal RAM. We recommend running the CoreMark demo first and getting familiar with the basic download process and hardware setup. Get the CoreMark result on internal flash/RAM. It provides a baseline score that can compare with FlexSPI external memory CoreMark data.

2.2 Changing code execution address

• Keil

Switch the project configuration to `lpc55s3x_coremark_flash` configuration.




Figure 1. Switching to lpc55s3x_coremark_flash configuration

Change the linker file to set code space to start from 0x0800_1000.




Figure 2. Changing linker file in Keil

• IAR

Switch the project configuration to lpc55s3x_coremark_flash configuration.




Figure 3. Switching to lpc55s3x_coremark_flash configuration and selecting LPC55S36_flash.icf

```

33
34 define symbol m_interrupts_start           = 0x08001000;
35 define symbol m_interrupts_end           = 0x080013FF;
36
37 define symbol m_text_start               = 0x08001400;
38 define symbol m_text_end                 = 0x0803FFFF;
39
40 define symbol m_data_start                = 0x20004400;
41 define symbol m_data_end                 = 0x20007FFF;
42
43 define symbol m_sramx_start               = 0x04000000;
44 define symbol m_sramx_end                 = 0x04003FFF;
45
    
```

Figure 4. Changing linker file in IAR

• **MCUX**

Open **Property > C/C++ build > MCU Settings** and change flash location to 0x0800_1000.




Figure 5. Changing linker file in MCUX

All other compile and download steps are the same as described in *Programming and Booting Images from External NOR flash on LPC553x/LPC55S3x* (document [AN13543](#)).

2.3 Enabling CACHE64

CACHE64 is a peripheral to accelerate FlexSPI performance. By default, CACHE64 is disabled. We must enable CACHE64.




Figure 6. Adding the CACHE64 init function in portable_init()

For more information about CACHE64, see *LPC55S36 Reference Manual*.

3 Coremark result (Octal Flash: MX25UM51345GXDI00)

- **Hardware:**
 - LPCXpresso55S36
 - External nor flash: MX25UM51345GXDI00
- **Internal Flash configuration:**
 - Cache enabled
 - Code in internal Flash
 - Data in SRAM
- **FlexSPI configuration:**
 - FlexSPI clock = FRO96M
 - CACHE64 enabled
 - Octal DDR mode
 - Code in external NOR flash
 - Data in SRAM
- IDE: All IDE optimization settings are the same as mentioned in *LPC553x/LPC55S3x CoreMark on Cortex-M33 Porting Guide* (document [AN13579](#)).

Table 1. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 12 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (FlexSPI NOR vs. Internal Flash)
KEIL	4.086	4.170	102 %
IAR	4.025	4.081	101 %
MCUX	2.964	2.971	101 %

Table 2. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 96 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (FlexSPI NOR vs. Internal Flash)
KEIL	3.986	4.011	100 %
IAR	4.023	4.080	101 %
MCUX	2.956	2.952	100 %

Table 3. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 100 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (FlexSPI NOR vs. Internal Flash)
KEIL	3.972	3.995	100 %
IAR	4.01	4.068	101 %
MCUX	2.945	2.938	99 %

Table 4. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 150 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (FlexSPI NOR vs. Internal Flash)
KEIL	3.905	3.874	99 %
IAR	4.004	4.062	101 %
MCUX	2.942	2.936	99 %

4 Coremark result (HyperRAM: W956D8MBYA5I)

By default, the FlexSPI is connected to octal NOR Flash on LPCXpresso55S36. Rework to enable HyperRAM. The LPCXpresso55S36 provides a rework guide on the schematic. The default configuration is for **4. MX25UM51345GXD100**. Change resistor setting and align to **3. APS6408L-OBM-BA**. For HyperRAM, we choose **W956D8MBYA5I** of Winbond (same configurations as APS6408L).

As HyperRAM cannot save any code and data when power off, you must write a simple loader in internal flash that performs the below tasks:

1. Convert the CoreMark image into a C data array and copy to the image start address in FlexSPI space.
2. Jump to the start address and execute the image.




Figure 7. Octal FlexSPI interface schematic for LPC553x/LPC55S3x

- **Hardware:**
 - LPCXpresso55S36 RevD
 - HyperRAM: W956D8MBYA51
- **Internal Flash configuration:**
 - Cache enabled
 - Code in internal flash
 - Data in SRAM
- **FlexSPI configuration:**
 - FlexSPI clock = FRO96 M
 - CACHE64 enabled
 - Octal DDR mode
 - Code in HyperRAM
 - Data in SRAM
- **IDE:** IDE optimization setting is the same as mentioned in *LPC553x/LPC55S3x CoreMark on Cortex-M33 Porting Guide* (document [AN13579](#)).

Table 5. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 12 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (HyperRAM vs. Internal Flash)
KEIL	4.086	4.173	102 %
IAR	4.025	4.041	100 %
MCUX	2.964	2.920	99 %

Table 6. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 96 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (HyperRAM vs. Internal Flash)
KEIL	3.986	3.991	100 %
IAR	4.023	4.010	99 %
MCUX	2.956	2.902	98 %

Table 7. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 100 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (HyperRAM vs. Internal Flash)
KEIL	3.972	3.971	100 %
IAR	4.01	4.039	100 %
MCUX	2.945	2.911	98 %

Table 8. LPCXpresso55S36 board CoreMark/MHz score when CoreClock = 150 MHz

IDE	CoreMark/MHz (Internal Flash)	CoreMark/MHz (FlexSPI)	Performance (HyperRAM vs. Internal Flash)
KEIL	3.905	3.842	98 %
IAR	4.004	4.049	101 %
MCUX	2.942	2.916	99 %

5 Conclusion

This application note extends the CoreMark project to FlexSPI external memory and gives a test result under different Core Clock configuration. Read this document as an extended version of *LPC553x CoreMark on Cortex-M33 Porting Guide* (document [AN13579](#)).

The FlexSPI NOR flash and HyperRAM CoreMark performance are similar to internal flash. There are limitless possibilities to extend the application code size without performance compromise.

6 Revision history

[Section 6](#) summarizes the revisions to this document.

Table 9. Revision history

Revision Number	Release date	Description
3	20 September 2023	<ul style="list-style-type: none"> Replaced "LPCXpresso55S36" with "LPCXpresso55S36 RevD" in Section 4 Made some editorial changes
2	13 December 2022	Update reference of AN12284 with AN13579
1	26 May 2022	Replaced LPC553x with LPC553x/LPC55S3x
0	18 March 2022	Initial release

7 Legal information

7.1 Definitions

Draft — A draft status on a document indicates that the content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included in a draft version of a document and shall have no liability for the consequences of use of such information.

7.2 Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Terms and conditions of commercial sale — NXP Semiconductors products are sold subject to the general terms and conditions of commercial sale, as published at <http://www.nxp.com/profile/terms>, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. NXP Semiconductors hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of NXP Semiconductors products by customer.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Suitability for use in non-automotive qualified products — Unless this data sheet expressly states that this specific NXP Semiconductors product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. NXP Semiconductors accepts no liability for inclusion and/or use of non-automotive qualified products in automotive equipment or applications.

In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without NXP Semiconductors' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond NXP Semiconductors' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies NXP Semiconductors for any liability, damages or failed product claims resulting from customer design and use of the product for automotive applications beyond NXP Semiconductors' standard warranty and NXP Semiconductors' product specifications.

Translations — A non-English (translated) version of a document, including the legal information in that document, is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

Security — Customer understands that all NXP products may be subject to unidentified vulnerabilities or may support established security standards or specifications with known limitations. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP.

NXP has a Product Security Incident Response Team (PSIRT) (reachable at PSIRT@nxp.com) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

NXP B.V. - NXP B.V. is not an operating company and it does not distribute or sell products.

7.3 Trademarks

Notice: All referenced brands, product names, service names, and trademarks are the property of their respective owners.

NXP — wordmark and logo are trademarks of NXP B.V.

AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamIQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro, μ Vision, Versatile — are trademarks and/or registered trademarks of Arm Limited (or its subsidiaries or affiliates) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved.

Contents

1	Introduction	2
2	Porting CoreMark project to FlexSPI external memory	2
2.1	Getting CoreMark demo source code	2
2.2	Changing code execution address	2
2.3	Enabling CACHE64	5
3	Coremark result (Octal Flash: MX25UM51345GXDI00)	5
4	Coremark result (HyperRAM: W956D8MBYA5I)	6
5	Conclusion	8
6	Revision history	8
7	Legal information	9

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.

© 2023 NXP B.V.

All rights reserved.

For more information, please visit: <http://www.nxp.com>

Date of release: 20 September 2023
Document identifier: AN13591